
Step 1

Parts Needed






Tips

- Make sure all the internal screws are very secure, as they will be hard to retighten later.
- The 7/64", 5/64" and 3/32" hex keys will be needed to build this model.
- \cdot Use the 7/64" hex key for these screws throughout the model.
- Ensure that the teeth of the nut face the head of the screw.

Step 2

Parts Needed






Tips

- Ensure that all screws are tightly secured at this point, as they will not be easily accessible later.
- Reminder: Ensure that the teeth of the nut face the head of the screw.

Step 3

Parts Needed






Tip

• Ensure that the teeth of the nuts are facing the gear.

Step 4

Parts Needed






Tips

- Use the Phillips head on the 4-in-1 screwdriver to tighten the servo screw. This will keep the servo horn attached to the servo motor.
- Use the 5/64" hex key for the BHCS.

Step 5

Parts Needed







Tip

 \bullet The 3/32" hex key is used on the axle hubs.

Step 6

Parts Needed






Tip

Step 7

Parts Needed






Tin

Step 8

Parts Needed






Tip


Step 9






Step 10

Parts Needed






Tip

Step 11

Parts Needed






Tip

• Use the Phillips head on the 4-in-1 screwdriver to tighten the servo screw. This will keep the servo horn attached to the servo motor.

Step 12

Parts Needed





Tir

• To keep the arm oriented properly, tighten the screws bit by bit, alternating between them.

Step 13





Step 14



2x 3-Module Connector Peg with Friction



2x 5-Module Beam




1x NXT Touch Sensor



1x 20-Tooth Gear




1x 2-Module Axle



Step 15

Parts Needed






Tip


• Turn the screws only until the hard point connector is securely attached to the TETRIX® channel.

Step 16





Final View




Servo Horn Adjustment

Note: Whenever a servo motor is used to attach an extension, care must be taken to properly adjust the servo motor position so that the desired range of motion is achieved. The best way to adjust the servo position is to unscrew the servo horn and use it, and the extension that has been built onto it, like a wrench.

Step 1 Starting Point:

Attach the servo horn to adjust the servo position.



Step 2 Rotate:

Rotate the servo so that it has been positioned at the end of its range of motion.





Step 3 Final Positioning:

Reattach the servo horn with the extension piece in the appropriate position for that servo location.



Wiring Diagram Touch Servo Servo Sensor Motor Motor Ultrasonic Sensor I DC Controller Servo Controller Light Sensor I **NXT** Battery Fuse Switch Right Motor Left Motor

Tips

• Tighten the screws on the HiTechnic controller after the wires have been inserted.

Complete all wiring before attaching the battery.