

# i-SOBOT™ Action Table

For combinations of multiple buttons, input in order from the left.

## Description of icons

- P** ...Punch button    **K** ...Kick button    **G** ...Guard button    **GO** ...Execute button
- 1** ...1 button    **2** ...2 button    **3** ...3 button    **4** ...4 button
- A** ...A button    **B** ...B button    **L** ...Left joystick    **R** ...Right joystick

## Remote control mode

Joystick Control				Punch Actions				Kick Actions				Guard Actions				Common Phrases & Greetings			
No	Action	Input & Movement	LCD	No	Action	Input	LCD	No	Action	Input	LCD	No	Action	Input	LCD	No	Action	Input	LCD
1	Walk Forward	L ↑	↑ 00	19	Punch (L)	1 P	1.P	35	Roundhouse (L)	1 K	1.K	50	Guard (L)	1 G	1.G	63	Affirm	1 A	1.A
2	Walk Backward	L ↓	↓ 00	20	Punch (R)	2 P	2.P	36	Roundhouse (R)	2 K	2.K	51	Guard (R)	2 G	2.G	64	Disagree	4 A	4.A
3	Walk Fwd Curve Left	L ↶	↶ 00	21	Backhand (L)	3 P	3.P	37	Forward Kick (L)	3 K	3.K	52	2-Hand Guard 1	3 G	3.G	65	Good Morning	1 2 A	1.2.A
4	Walk Fwd Curve Right	L ↷	↷ 00	22	Backhand (R)	4 P	4.P	38	Forward Kick (R)	4 K	4.K	53	2-Hand Guard 2	4 G	4.G	66	Greet 1	1 3 A	1.3.A
5	Sidestep Left	L ←	← 00	23	One-Two Punch (R)	1 2 P	1.2.P	39	Side Kick (L)	1 1 K	1.1.K	54	Dodge Left	1 1 G	1.1.G	67	Greet 2	2 1 A	2.1.A
6	Sidestep Right	L →	→ 00	24	One-Two Punch (L)	2 1 P	2.1.P	40	Side Kick (R)	2 2 K	2.2.K	55	Dodge Right	2 2 G	2.2.G	68	Greet 3	2 2 A	2.2.A
7	Walk Bkwd Curve Left	L ↶	↶ 00	25	Chop (L)	1 1 P	1.1.P	41	Back Kick (L)	3 3 K	3.3.K	56	Duck	3 3 G	3.3.G	69	Greet 4	2 3 A	2.3.A
8	Walk Bkwd Curve Right	L ↷	↷ 00	26	Chop (R)	2 2 P	2.2.P	42	Back Kick (R)	4 4 K	4.4.K	57	Sway Back	4 4 G	4.4.G	70	Bye 1	3 1 A	3.1.A
9	Rotate Fwd Clockwise	L ↻ R ←	↻ 00	27	Double Chop	3 3 P	3.3.P	43	Roundhouse (L & R)	1 2 K	1.2.K	58	Up-sweep Block	1 2 G	1.2.G	71	Bye 2	3 2 A	3.2.A
10	Rotate Fwd Counter-CW	L ↻ R →	↻ 00	28	Upper Chop	4 4 P	4.4.P	44	Fwd Kick (L & R)	2 1 K	2.1.K	59	Splits 2	3 4 G	3.4.G	72	Bye 3	3 3 A	3.3.A
11	Rotate Bkwd Clockwise	L ↻ R ←	↻ 00	29	Combo Punch	1 2 3 4 P	1.2.3.4.P	45	Combo Kick	1 2 3 4 K	1.2.3.4.K	60	Combo Guard	1 2 3 4 G	1.2.3.4.G	73	Bye 4	3 4 A	3.4.A
12	Rotate Bkwd Counter-CW	L ↻ R →	↻ 00	30	Side Chop (L)	1 4 P	1.4.P	46	High Kick (L)	1 3 K	1.3.K	<b>Stand up from a Prone Position</b>				74	Bye 5	1 4 A	1.4.A
13	Move Arms	R button + L R	ARMS	31	Side Chop (R)	2 3 P	2.3.P	47	High Kick (R)	2 4 K	2.4.K					61	Stand up (if face down)	A	A
14	Lock/Unlock Arms	L button (R button + L R)	ARMS	32	Slapping	4 3 P	4.3.P	48	Splits 1	3 4 K	3.4.K	62	Stand up (if face up)	B	B	76	Thanks 1	4 1 A	4.1.A
15	Turn Head Left	R ←	↶	33	Double Backhand	3 4 P	3.4.P	<b>Utility Action</b>				"Do not use Actions 61 & 62 unless i-SOBOT is lying down as noted. If used when standing, i-SOBOT will fall abruptly, risking damage."				77	Thanks 2	4 2 A	4.2.A
16	Turn Head Right	R →	↷	<b>Programming Pause</b>												49	Zero Position	4 4 4 B	4.4.4.B
17	Lean Forward	R ↑	↶	34	3 Second Pause	4 4 4 A	4.4.4.A	"Action 49 is normally used only for maintenance"				79	Love 2	2 2 2 A	2.2.2.A				
18	Lean Backward	R ↓	↷									80	Love 3	3 3 3 A	3.3.3.A				



# i-SOBOT™ Action Table

For combinations of multiple buttons, input in order from the left.

### Description of icons

- P** ...Punch button
- 1** ...1 button
- A** ...A button
- K** ...Kick button
- 2** ...2 button
- B** ...B button
- G** ...Guard button
- 3** ...3 button
- L** ...Left joystick
- GO** ...Execute button
- 4** ...4 button
- R** ...Right joystick

## Remote Control Mode (cont.)

Emotional Actions				Showcase Actions			Showcase Actions (cont.)				
No	Action	Input	LCD	No	Action	Input	LCD	No	Action	Input	LCD
81	Excited 1	1 4 B	1.4. B	97	Hide N Seek	3 1 B	3.1. B	114	Lift	2 2 2 B	2.2. B
82	Excited 2	2 1 B	2.1. B	98	You Like?	1 2 4 A	1.2. A	115	Count on Me	2 2 4 B	2.2. B
83	Excited 3	2 2 B	2.2. B	99	Mystery 5	1 3 1 A	1.3. A	116	Articulation	2 3 1 B	2.3. B
84	Excited 4	1 2 2 B	1.2. B	100	Tipsy	1 3 2 A	1.3. A	117	Show Off 1	2 3 2 B	2.3. B
85	Party	1 3 B	1.3. B	101	Tickle Me i-SOBOT	1 4 1 B	1.4. B	118	Show Off 2	2 3 3 B	2.3. B
86	Amazed	1 2 4 B	1.2. B	102	Tired Feet	1 4 2 B	1.4. B	119	Show Off 3	2 3 4 B	2.3. B
87	Regret 1	2 4 B	2.4. B	103	Need a Break	1 4 3 B	1.4. B	120	Show Off 4	2 4 1 B	2.4. B
88	Regret 2	3 3 B	3.3. B	104	Wave 1	1 4 4 B	1.4. B	121	Comin' Through	2 4 2 B	2.4. B
89	Regret 3	3 4 B	3.4. B	105	Wave 2	2 1 1 B	2.1. B	122	Catch	2 3 B	2.3. B
90	Worry	3 2 B	3.2. B	106	Applause	1 3 3 B	1.3. B	123	Pose 1	4 1 1 A	4.1. A
91	Pain 1	4 2 B	4.2. B	107	Mystery 6	1 1 4 B	1.1. B	124	Pose 2	4 1 2 A	4.1. A
92	Pain 2	4 4 B	4.4. B	108	Too Sexy	2 1 2 B	2.1. B	125	Pose 3	4 1 3 A	4.1. A
93	Beg 1	4 1 B	4.1. B	109	Clink	2 1 3 B	2.1. B	<b>Mystery Actions</b>			
94	Beg 2	1 1 3 B	1.1. B	110	Relax	2 2 1 B	2.2. B				126
95	Merry	1 2 1 B	1.2. B	111	Soccer 1	2 2 3 B	2.2. B	127	Mystery 2	1 3 1 B	1.3. B
96	Hilarious	1 3 4 B	1.3. B	112	Soccer 2	4 2 K	4.2. K	128	Mystery 3	1 3 2 B	1.3. B
				113	Soccer 3	3 1 K	3.1. K	129	Mystery 4	4 3 B	4.3. B

## Special Action Mode

No	Action	Input	LCD
130	Forward Somersault	A GO	SA-01 A.
131	Headstand Exercises	B GO	SA-02 B.
132	Excercises	A B GO	SA-03 A.B.
133	Air Drum	A A A GO	SA-04 A.A.A.
134	Air Guitar	B B B GO	SA-05 B.B.B.
135	Random performance		SA-06 B.A.B.
136	Banzai! Japan Cheer 1 Japan Cheer 2	B A B GO	SA-07 B.A.B.
137			SA-08 B.A.B.
138			SA-09 A.B.B.
139	Randomly imitates an animal		SA-10 A.B.B.
140	Dog Cat Eagle Rooster Gorilla	A B B GO	SA-11 A.B.B.
141			SA-12 A.B.B.
142			SA-13 A.B.B.
143	Tropical Dance	B B A GO	SA-14 B.B.A.
144	Giant Robot	A B A GO	SA-15 A.B.A.
145	Western Movie Scene	A B A B GO	SA-16 A.B.A.B.
146	Random Performance Martial Arts Tai Chi	A A A A GO	SA-17 A.A.A.A.
147			SA-18 A.A.A.A.

## Voice Control Mode

No	Voice Command	Action	LCD
148	Go Forward	Walks Forward	VC-MODE
149	Turn Left	Rotates Left	VC-MODE
150	Turn Right	Rotates Right	VC-MODE
151	Back up	Steps back	VC-MODE
152	Action Start	Special Performance	VC-MODE
153	How are you?	Appropriate Response	VC-MODE
154	What's up?	Appropriate Response	VC-MODE
155	i-SOBOT	Appropriate Response	VC-MODE
156	Look out!	Appropriate Response	VC-MODE
157	Make me laugh	Appropriate Response	VC-MODE



3 2008

"Actions 99, 75 and 126-129 have no sound."